

## How to Apply Your Iron-On Heat Transfer

The Iron-On Heat Transfer comes to you ready to be ironed on to your fabric or T-shirt.

1. Pre-heat your iron to the temperature fit for your fabric.



2. Slowly peel off the white plastic backing from the clear, sticky plastic where the stones are attached.



3. Place the clear, sticky plastic on your garment or fabric with the adhesive (sticky) side down. Be sure to put it exactly where you want it.

To protect your fabric from your hot iron, we recommend that you put a light covering cloth or even a paper towel the size of your iron over the motif before ironing. **(NOTE: Clark actually prefers to carefully turn the shirt inside out and iron directly on the fabric, so the heat source is closer to the back side of the crystals/glue)**



4. Now get your iron and with the steam turned off, put it down directly on the motif area. Press only. Do not move your iron. Let it stay in place for at least 20 seconds and then lift.



5. Be careful. The clear plastic will be hot!! Allow to cool and then slowly pull off the adhesive clear plastic from your fabric. If some of the rhinestones are still attached to the clear plastic, put the clear plastic back to your fabric and then re-press those parts again.



6. Press the back side of the fabric also. Remember that the most important part here is the melting of the glue at the back of the rhinestones so that they will stick to the fabric.



After removing the clear plastic and all the rhinestones have attached themselves to the fabric, put back the light covering cloth or paper towel and re-press again both front and back.

**DISCLAIMER:** We do not recommend the use of the iron or heat press on leather, PVC, polyamide, rubber, plastic, fabrics with silicone or wax finish and the likes.